

Logitech C920s Pro HD Webcam

Introduction

This document includes quick start instructions for using the **Logitech C920s Pro HD Webcam**. This camera is **plug-and-play**, meaning installation requires no additional software to be downloaded for use with Edge.



Installation

1. Connect the camera to your computer using the attached **USB cable**.
2. Microsoft Windows will **automatically** detect the camera and begin installing it. Follow any on-screen setup instructions to complete the installation.

Configuring the Camera in Edge

1. Start The Edge and select **Administrative > Select Photo Device**. A list of devices will appear.
2. Choose the **Logitech** option and select **OK**.
3. Select **Administrative > Configuration > Camera – Set Camera Driver to Current**.
4. Select **OK** to save your changes.
5. Restart The Edge.

Taking Pictures

1. Pictures can be acquired anywhere in The Edge where you see the **camera icon** (e.g., Items, Repairs, Customers).
2. To take a picture, click the camera icon, then select **Acquire**. You may be prompted to select the device. If so, select **Logitech**.
3. Manipulate the **Camera, Item, or Photo Box** to get a clean picture.
4. When you are ready, select **Acquire** to take the picture.